



## PRODUCT INFORMATION

### SULTRAPON EU<sub>3</sub>

Sultrapon EU<sub>3</sub> is a concentrated detergent for use in perchloroethylene. If sufficient is used correctly the product is capable of contributing towards excellent cleaning and imparting to dry cleaned work a pleasant handle without static. Sultrapon EU<sub>3</sub> can also be used as a pre wash detergent in conjunction with Sultrasoft HC2 to give the best cleaning and finish

#### METHODS OF USE.

Any conventional P process.

#### EMULSION PREPARATION

For perchloroethylene pre-spotting purposes 1:1 with water

#### PRESPOTTING SENSITIVES (Options)

Consider if it is safe to pre-treat the garment at all. If so: - Cleaner S may be used, with care, on most sensitive fabrics. Cleaner IA may be used, with care, on most sensitive dyestuffs. Sultrapon EU<sub>3</sub> can be used as a prespotter on more sensitive garments neat.

#### PRESPOTTING NORMALLY ROBUST GARMENTS IN PERCHLOROETHYLENE

Use a mixture of one part Sultrapon EU<sub>3</sub> with one part of water, at your discretion, and with only an appropriate amount of friction.

#### USING SULTRAPON EU<sub>3</sub> IN PERCHLOROETHYLENE MACHINES.

Charge the solvent, including the filter contents, with between 3mls (min) and 5mls (max.) per litre. Replace detergent lost through distillation at the same rates. Charge new solvent at the same rate when it is added to the machine.

All the information contained herein is correct to the best of our knowledge and belief, but as we have no control over the use of our product in your hands it is offered without guarantee.